

Fixed Width Skyscraper Mount™ - SKMM Series

For ALL 96" tall units (SKMM148, SKMS8, SKMM248, SKMM368, SKMM488, SKMM608) or taller, the uprights are split in half. Each upper section will have to have two pre-attached joining rods sticking out of the bottom.

1. Attach each upright (or bottom upright section if upright is split in half) to the base, using screws provided.
2. **IF UPRIGHT IS SPLIT IN HALF:** Fully insert the rods of the upper section into the semi-circular holes inside the bottom upright. Fasten the upper section to the bottom section using the short hex screws provided. Attach one screw from the front face and one screw from the back face of each upright. Only tighten screws enough for screw to come to a stop with MINIMAL effort. **OVERTIGHTENING MAY CAUSE INDENTING OF THE FACE OF THE LOWER UPRIGHT.**
3. Insert the graphic from above, into the channel of the uprights.
4. Use the Allen key provided to tighten all set screws.

