

Add-on Accessory for Hand Sanitizer Stand - HSD-ADD-STRAP

1. With the Hand Sanitizer Plate and Dispenser firmly supported, remove the screws or knob that attach the Hand Sanitizer Plant to the upright. Detach the Hand Sanitizer Plate and Dispenser temporarily.
2. Place the horizontal tab of the Add-on Accessory Plate (which has 3 holes) between the top of the upright and Hand Sanitizer Plate. The Add-on Accessory Plate goes UNDER the Hand Sanitizer Plate. Then reattach the screws or knob to the upright from above by passing them through the holes of the Hand Sanitizer Plate, then the Add-on Accessory Plate, and into the upright. Fasten securely.
3. Place your gloves, sanitizer wipes, masks box, or other lightweight item inside of the Velcro straps of the Accessory plate and firmly secure the straps. The strap is designed to go around an item, loop back through the plate, and secure to the beginning of the strap behind the plate as shown in #2 "Back View" below. If you have an excess amount of Velcro you may choose to trim Velcro, though leaving extra Velcro may allow for holding larger items in the future.

